

Item # SPEAKERX7

Wireless Speaker Manual



HAVE QUESTIONS OR PROBLEMS?
CALL CUSTOMER SERVICE BEFORE RETURNING TO THE RETAILER!
CONTACT CUSTOMER SERVICE at 636-532-9888

INTRODUCTION

Bluetooth Wireless Technology Enabled Product

This wireless speaker works with smart phones, tablets and computers which provide Bluetooth® functionality. You can stream music and use as a hands-free speakerphone.

FEATURES

- Volume and song control directly on speaker unit
- Dual pairing function
- Stunning sound clarity
- Ultra portable design
- Water-resistant design is great for parties, indoor and outdoor
- Bluetooth® Wireless Technology to make & answer phone calls

SPECIFICATIONS

Loudspeaker: 4Ω 5W
Built-in Battery Power: Li-ion 1000mAh
Dimensions: 3.6 in(W)*3.6 in(L)*1.6 in(H)
SNR:80± 3dB
Wireless Working Frequency: 2.402-2.480 Ghz
Wireless Transmission Distance: up to 32 ft from source
Charging Time: 3 hours
Weight: 5.8 oz
Speaker Dimension: 1.7 in
Charging: 5 V, 500mA
Rated IPX7 Water-Resistant

IMPORTANT WATER-RESISTANT SAFETY INFORMATION

CAUTION: DO NOT submerge the speaker in water! This unit is not intended to function properly after being under water. It is rated IPX7, which means it is protected against water immersion for less than 30 minutes at a depth of less than 3 feet. If the speaker gets wet, it is recommended that you dry the speaker completely.

IMPORTANT SAFETY PRECAUTIONS

When using your Bluetooth® Mobile Speaker, basic safety precautions should always be followed, including the following:

1. Keep this product and its charging cable away from excessive heat.
2. Do not operate this device with a damaged cable or after it has malfunctioned or has been damaged in any manner.
3. Do not disassemble your device.
4. Only use your device on a flat, stable surface.


CHARGING YOUR SPEAKER

1. Connect one end of the included USB Charging Cable to the Charging Port on your speaker. Then plug the other end of the USB Charging Cable into a suitable USB port on your computer to recharge your speaker's internal rechargeable battery.


NOTE: The internal battery of your speaker takes approximately two hours to charge when completely drained.

2. When charging, a red LED light will illuminate to indicate that the unit is charging. The red light will turn off when your unit is fully charged in about 3 hours.

A Quick Look at Your Device




1. Previous: Press and hold to access the last track in playlist. Press to lower the volume.
2. Phone: Press this button to activate the the speaker phone function. When music is playing, press to play or pause a track.
3. Next : Press and hold to access the next track in a playlist. Press to increase the volume.



1. Charging Port

You can plug one end of the included USB Charging Cable into this jack, while plugging the other end into a USB port on your computer in order to charge your speaker's built in lithium battery.



2. ON/OFF Switch

Press and hold the " "for power on
Press and hold the " "again for power off

Understanding the LED Light Status

When Charging Your Speaker

Solid red LED = Charging

No red LED = Charge Complete

When Pairing To A Bluetooth Audio Source:

Rapid blinking blue LED: Bluetooth not connected (ready to pair)

Solid blue LED: Bluetooth connected.

How to Get Started

In order to connect your Bluetooth® device, you must first pair both the speakers together.

How to Pair Speakers Together

- 1). Power on both speakers. When powered on, press the " " button, the two speakers will automatically connect to each other. Successful LED status: One Bluetooth LED light is steady and another flashes.
- 2). Once paired, speakers will Chime.

Pairing Bluetooth Devices to Your Speaker

- 1). Make sure your Bluetooth® audio source is held within 9 feet of your speaker.
- 2). Press and hold the " " switch on your speaker to power on. The LED light will blink blue to indicate that you have entered pairing status.
- 3). Go to the Bluetooth® Manager of your Bluetooth® audio source. Refer to the User's Manual of your Bluetooth® audio source for information.
- 4). Search Bluetooth® devices, select "SPEAKERX7".
- 5). Once paired, the blue LED light will be solid and you can use your speaker to listen to audio from your Bluetooth® sound source.

Using Hands-Free Function With iPhone or Smartphone


1. Press " "to pick up the call.
2. Press and hold " "for 2 sec to reject the call.
3. During a call: Press " "again to hang up the call.

TROUBLESHOOTING

Problem	Solution
The speaker doesn't connect to device	Speaker needs to be connected/re-paired to device
A tone is heard every few seconds	Speaker needs to be charged
Bluetooth connection distance cannot reach to 32 ft.	Avoid operating the Bluetooth® speaker in areas of strong electromagnetic interference, such as near induction cookers, large power fans, motors etc. Move the speaker closer to Bluetooth device. Fully charge the speaker and try again.
The speaker will not power on	Speaker needs to be charged
The speaker doesn't control	Speaker needs to be in Bluetooth® mode for full control
The speaker distorts at high volume	The devices' volume needs to be lowered




PACKAGE CONTENTS



1. Bluetooth® Speaker



2. USB Charging cable



3. User manual