

SSFP STAINLESS STEEL FIRE PIT ASSEMBLY INSTRUCTIONS

FOLLOW ALL SAFETY WARNINGS



WARNING: This outdoor fire pit is for outdoor use only. Use only on brick, concrete, stone or other masonry surfaces.



WARNING: Do not leave unattended at anytime during use.



WARNING: Use only on brick, concrete, stone or other masonry surfaces.



WARNING: Do not move the fire pit during use.



WARNING: Do not use on lawns, wooden decks, artificial wood decking or asphalt.



WARNING: Do not use in windy conditions.



WARNING: Keep the outdoor fire pit a minimum of 10 ft. away from buildings, structures, any flammable items and vehicles.



WARNING: The outdoor fire pit is for adult use only.



WARNING: Never use under low hanging tree branches, trellises or overhangs of any kind including covered porches.



WARNING: Use caution when tending the fire, as surfaces will become very hot while in use.



WARNING: Never use gasoline, alcohol or volatile fluids to start or restart fires.



WARNING: CARBON MONOXIDE HAZARD! Burning wood or charcoal produces carbon monoxide, which has no odor and can cause death if burned in enclosed areas. Never burn wood or charcoal inside homes, vehicles, tents or any other enclosed areas.



WARNING: For longer product life, keep fires to a respectable size, do not overload.



WARNING: Use caution after the fire has been extinguished. Surfaces will remain hot for some time.

SSFP STAINLESS STEEL FIRE PIT ASSEMBLY INSTRUCTIONS

COMPONENTS LIST


2 Pieces Stainless Steel Panels (A)

3 Pieces Stainless Steel Panels (B)

Note the difference between (A) and (B)
is the position of the SLOTS on the sides:

Panels (A) have both SLOTS on top.

Panels (B) have SLOTS on both top and bottom.



ASSEMBLY

1. Locate Panel (A).
2. Insert Panel (B) into top SLOT.
3. Insert another Panel (B) into opposite side SLOT.
4. Repeat by inserting all remaining panels.

