


## ITEM # PUT66 POP UP CANOPY TENT

### Contents:

- A Tent (1 piece)
- B Support Rods (2 pieces)
- C Carry Bag (1 piece)




### How To Assemble:

1. Remove contents from carry bag.

2. Pull out Middle Stem (D) on each side wall. Step inside tent, push up top ceiling panel into the shape of a pyramid.



3. Unbend the two Support Rods (E), insert each into Top (F) and Bottom (G) door pockets.



## ITEM # PUT66 POP UP CANOPY TENT

### How To Disassemble:

1. Remove both Support Rods from the door the door pockets.
2. Push all inside side walls and gather fabric tightly.
3. Roll the tent, and slide the Support Rods inside, and insert into the Carry Bag.

### IMPORTANT

- Take tent down during high wind.
- Let tent dry before closing.
- Do not store when fabric is wet.
- Use mild detergent to clean surface.
- Do not leave tent unattended.

### CAUTION

Do not attempt to erect this popup tent during windy conditions, or injury or damage could occur.

**MADE IN CHINA**