Follow This Step-By-Step Guide To Using Your Generator

Remove Generator From Package

Add Oil

Oil Type: SAE10W-30 Oil (Must add BEFORE first use) Oil Capacity: 22.0 fluid oz

Because this generator includes Low Oil Shut Off, the generator will not start with low oil. Start out with 22.0 oz, then **fill until almost overflowing**.)

Unleaded gasoline only octane rating of 87 or higher Maximum Capacity: 4.5 Gallon fuel tank

4 Start The Generator

Add Fuel

- Use the generator OUTDOORS in a WELL VENTILATED AREA.
- DO NOT CONNECT electrical devices until AFTER the generator is started.
- Turn Power Switch to ON
- Turn FUEL SWITCH to ON (Figure A)
- Pull out the CHOKE LEVER fully to Start (Figure B)
- Start the generator manually with the Recoil (Pull) Start.
- Once the engine has started, GRADUALLY push the choke lever halfway to warm up until the engine levels off. Then push in completely to run.
- Wait approximately 5 minutes BEFORE adding appliances or tools



Fuel Switch (Figure A)



Choke (Figure B)

GEN4000IOF

3,850 Surge / 3,500 Running Watts

UNLEADED GASOLINE FUEL

GENERATOR SPECIFICATIONS:

- 2 120V A/C Outlets
- 1 120V RV Outlet
- 2 x USB Ports
- · Recoil Start
- Parallel Port Output Capability (Parallel Cable Available Separately)
- Sine Wave Output For Sensitive Electronics
- 6.5 HP OHV Engine
- · Displacement: 223cc
- · Phase: Single
- · AC Voltage: 120V @ 60Hz
- Decibel Rating <65 db @ 24 Feet
- · Complies with EPA emissions
- Engine Run Time: 10 Hours @ 50% Load
- Fuel Tank Capacity: 4.5 Gallon
- DO NOT use E85, gas/oil mix, or modify the engine to run on alternate fuels.
- High Altitude Use: This generator is not recommended for high altitude use 3,000 feet above sea level.
- If you are using a generator at 3,000 feet above sea level, the generator may not function properly because of air flow getting through the carburetor.
- Warranty: 2 YEAR Limited Emissions
- · Warranty: 1 YEAR Limited

OIL IS NOT INCLUDED WITH THIS GENERATOR. IT IS SOLD SEPARATELY.

Read and understand instruction manual before using generator.



Always follow Warning labels placed on the generator, and read and follow all Warning labels included inside the Product Manual.

WARNING: NEVER use a generator inside a home or a garage, EVEN IF the doors and windows are open.

ONLY USE OUTSIDE and far way from windows, doors and vents leading into an enclosed area.

Using a generator indoors can kill you in minutes. The generator produces an exhaust that contains carbon monoxide. This is a poison you cannot see or smell.

Do not attach a chain or rope to secure the generator to a post as this can be difficult to remove in the event of an emergency.




TOLL-FREE NATIONWIDE HELP LINE! 866-460-9436




This generator includes a built-in Carbon Monoxide Warning Alert! The generator will automatically shut-off if dangerous levels of Carbon Monoxide is detected. Need Help? Call Customer Service! Monday-Friday 8:00 AM - 4:00 PM Central Time





DO NOT CONNECT electrical devices until AFTER the generator is started.





IF THERE IS ANY QUESTION ABOUT A CONDITION BEING SAFE OR UNSAFE, DO NOT OPERATE THIS PRODUCT!

Always follow Warning labels placed on the generator, and read and follow all Warning labels included inside the Product Manual.

WARNING: NEVER use a generator inside a home or a garage, EVEN IF the doors and windows are open.

ONLY USE OUTSIDE and far way from windows, doors and vents leading into an enclosed area.

Using a generator indoors can kill you in minutes. The generator produces an exhaust that contains carbon monoxide. This is a poison you cannot see or smell.

Do not attach a chain or rope to secure the generator to a post as this can be difficult to remove in the event of an emergency.

TOLL-FREE NATIONWIDE HELP LINE! 866-460-9436

Need Help? Call Customer Service! Monday-Friday 8:00 AM - 4:00 PM Central Time

